



Electrical faults: IDG Fail, BTB open, DCIR open, and Unsynchronized AC Bus

- IDG Fail:** Associated AC bus (AC Bus 1 in this case) is powered by the Sync Bus.
- BTB open:** Associated AC bus (AC Bus 2 in this case) remains powered by its generator.
- DCIR open:** Associated DC bus (DC Bus 2 in this case) remains powered by its TR.
- Unsynchronized AC Bus:** Associated BTB (BTB 4 in this case) opens.